Panasonic

TX–28DK20F

Colour television

Quintrix

100Hz SUPER DIGITAL SCAN

WIDE DIGITAL P–L–U–S

Q Link

Operating Instructions

English

TQB8E3352–eng

(unapproved issue – for information only)

WELCOME

Dear Panasonic Customer,
Welcome to the Panasonic family of customers. We hope that you have many years of enjoyment from your new colour television. This is a very advanced television; however, the Quick Start Guide will tell you how to have the TV operating quickly. You can then read the instructions completely and retain them for future reference.

CONTENTS

Warnings and Precautions **2**

Accessories **3**

Quick Start Guide **4**

Basic Controls **5**

Using the On Screen Displays **6**

Aspect controls **7**

Picture Menu **10**

Sound Menu **11**

Setup Menu **12**

Tuning Menu **13**

Tuning Menu – Programme edit **14**

Tuning Menu – Auto Setup **18**

Tuning Menu – Manual tuning **19**

OSD Language **20**

Q-Link **21**

AV Select and Setup **22**

VCR/DVD Operation **23**

Teletext Operation **24**

Audio / Video (AV) Connections **26**

Via the front AV3 Audio / Video (RCA) and Headphone Sockets 26

SCART and S-Video Terminal Information 26

Via the rear AV1 / AV2 21 Pin (SCART) and RCA Audio Out terminals 27

Troubleshooting **28**

For your guidance **28**

Specifications **29**

WARNINGS AND PRECAUTIONS

- This TV set is designed to operate on A.C. 220 – 240V, 50Hz.
- To prevent damage which might result in electric shock or fire, do not expose this TV set to rain or excessive moisture.
- **WARNING : HIGH VOLTAGE !!!**
  Do not remove the rear cover as live parts are accessible when it is removed. There are no user serviceable parts inside.
- Avoid exposing the TV set to direct sunlight and other sources of heat.
- The On/Off switch on this model does not fully disconnect the TV from the mains supply. Remove the mains plug from the wall socket when the TV set is not used for a prolonged period of time.
- **CABINET AND PICTURE TUBE CARE**
  Remove the mains plug from the wall socket. The cabinet and picture tube can be cleaned with a soft cloth moistened with mild detergent and water. Do not use solutions containing benzol or petroleum. TV sets can produce static electricity, care must be taken whenever touching the TV screen.
- Adequate ventilation is essential to prevent failure of electrical components, we recommend that a gap of at least 5cm is left all around this television receiver even when it is placed inside a cabinet or between shelves.

Check that you have the accessories and items shown

☐ Operating Instruction book

☐

Remote Control Transmitter
EUR511211

☐ Batteries for the Remote Control Transmitter.
(2 x R6 (UM3) size)

☐



TV Guarantee

Remote control batteries



- Make sure that the batteries are fitted the correct way round.
- Do not mix old batteries with new batteries. Remove old, exhausted batteries immediately.
- Do not mix different battery types, i.e. Alkaline and Manganese or use rechargeable (Ni–Cad) batteries.

QUICK START GUIDE

1 Plug in aerial and connect ancillary equipment.



2



First, ensure that the **VCR is in Standby mode.**

Plug in TV and switch on.

3



Select your country

For Switzerland and Belgium, select the desired language

Press the red button

4



Auto setup will begin, your stations will be located and stored.

Use the Programme Edit menu to delete unwanted stations (see page 14).

Press the TV/AV button to exit. TV/AV

5



If you are installing a new Q–Link compatible VCR, you can now switch it ON. Downloaded tuning data will match the television's.
If you are installing a new NEXTVIEWLINK compatible VCR, you will need to initiate download manually.
See the VCR handbook for details.

- If the VCR has not accepted download data from the TV, you may need to select the Download option from the VCR's menu.
- If Q–Link is not operating correctly, check it is connected to the television's AV2 socket, the SCART lead is a "full function" type, and the VCR is compatible with Q–Link, NEXTVIEWLINK or similar technologies. Ask your dealer for further details.
- For further information on Q–Link and connecting equipment, see pages 21, 26 and 27.

BASIC CONTROLS : FRONT PANEL AND REMOTE CONTROL



Red light indicates Standby mode.

MAINS
Power On/Off switch

STR (Normalisation store)
Used to store tuning and other function settings

F (Function select)
Displays the On Screen Display functions, use repeatedly to select from the available functions - Volume, Contrast, Brightness, Colour, Sharpness, Tint (in NTSC mode), Bass, Treble, Balance and Tuning mode.

RCA Audio/Video sockets (page 26)

S–VHS socket (see page 26)

Headphone socket (see page 26)

TV/AV switch (see page 22)

Increases or decreases the programme position by one. When a function is already displayed, press to increase or decrease the selected function.

Standby ON/OFF switch
Switches TV On or Off standby.

Menu buttons
Press to access the Picture, Sound and Setup menus (see page 6)

Status button
Press to display programme position, programme name, channel number, TV system, time stereo mode and programme table

Teletext buttons (see page 24)

Direct TV Record button (see page 21)

Ambience on/off

Aspect control button (see page 10)

Direct Channel Access
During normal TV viewing or when in the Tuning, Programme edit or Manual tuning menus, press and then enter channel number using the numeric buttons

The N button will recall settings stored with STR

STR (Normalisation store)



Sound mute On/Off

Cursor buttons to make selections and adjustments

Switch between viewing TV or AV input (see page 22)

Coloured buttons used for
Programme Edit functions (see page 14)
Teletext functions (see page 24)
AV selection (see page 22)

Programme / channel change buttons (0-9) and Teletext page buttons (see page 24)

Programme position for selection of two digit programmes (10-99) using numeric buttons

VCR / DVD buttons (see page 23)

The Help button provides a demonstration of On Screen Display menus

This TV has a comprehensive system of On Screen Display menus to access adjustments and options



Some selections, for example, **Contrast, Brightness, Colour** and **Sharpness** will allow you to increase or decrease their level.

Some selections, for example, **Off timer**, allow a choice to be made.

Some selections, for example **Tuning menu**, will lead to a further menu.

The **PICTURE**, **SOUND** and **SET UP** buttons are used to open the main menus and also to return to the previous menu.

The up and down cursor buttons are used to move the cursor up and down the menus.

The left and right cursor buttons are used to access menus, adjust levels or to select from a range of options.



The **STR** button is used to store settings after adjustments have been made or options have been set.

The **TV/AV** button is used to exit the menu system and return to the normal viewing screen.

The **HELP** button will run a demonstration of the menus available. Press the **HELP** button and select one of the options.

If the **HELP** button is pressed whilst a menu is displayed, the 'Instructions' box will be hidden from view. Press the **HELP** button again to show the 'Instructions' box.

ASPECT CONTROLS

The widescreen TV will allow you to enjoy viewing the picture at its maximum size, including widescreen 'cinema format' pictures.

Note: Just mode is not available when viewing an RGB source.

Press the ASPECT button to move through the six aspect options: Panasonic Auto, 4:3, Zoom, S–Zoom, 16:9 (Full) and Just

ASPECT

Panasonic Auto

Some broadcasts are transmitted together with a wide screen identification signal (WSS). If the TV receives this signal then it will automatically switch to wide screen 16:9 mode, maximum display.
The automatic widescreen switching depends upon reception conditions and the strength of the signal. If the signal is poor and therefore the WSS is weak then it is possible that the picture may not expand to full size and that the TV will display black areas around the edges.
If the original source signal was a standard 4:3 aspect ratio then you might prefer to view it in its original size; the red and green keys that appear will allow you to choose between viewing at standard **4:3** size or expanded in **Just** mode.



Panasonic Auto

4:3

4:3 will display a 4:3 picture at its standard 4:3 size and can be selected if you wish to view in this format.

4:3

Zoom

Zoom mode magnifies the central section of the picture.

The picture can be moved and enlarged vertically using the coloured keys. The former adjustment is useful for viewing any sub–titles which may appear outside the picture.



Zoom

The on screen selector keys that appear for some aspect functions will clear after a few seconds. If you subsequently wish to select an operation then press the Aspect key once more for the keys to reappear.

The widescreen aspect ratios of different films and programmes can vary. If these are wider than a standard 16:9 aspect picture then a black band may be visible at the top and bottom of the screen.
If, in Panasonic Auto mode, you experience problems with the screen display size when playing back widescreen format recordings from your VCR then it is possible that the tracking control of your VCR requires adjustment (your VCR instruction book will contain adjustment details).



Blue key has been pressed to move picture upwards

S–Zoom

S–Zoom allows increased magnification and the ability to move the picture horizontally and vertically.



Increased magnification with **S–Zoom**

16:9 (Full)

16:9 (Full) will display the picture at its maximum size but with slight elongation.

16:9 (Full)

ASPECT CONTROLS

Just

Just mode will display a 4:3 picture at maximum size but with aspect correction applied to the centre of the screen so that elongation is only apparent at the left and right edges of the screen. The size of the picture will depend on the original signal.

Just

STILL CONTROL

STILL Control
The STILL key allows you to freeze the picture at any time.

PICTURE MENU

This menu allows you to make adjustments to the picture quality

Open the Picture menu

Move to your choice

Increase or decrease levels or set options

Press the TV/AV button to exit the Picture menu





Contrast

Brightness

Colour

Sharpness

The Contrast, Brightness, Colour and Sharpness levels can be adjusted to suit your own preferences and the viewing conditions.

Tint

The Tint adjustment will only appear as a menu item if you have an NTSC signal source connected to the TV and will allow adjustment of the hue.



Colour balance

○●○

The Colour balance setting allows you to set the overall colour tone of the picture.

P-NR

●○

P-NR will automatically reduce unwanted picture interference.

AI

○●

The AI setting automatically analyses the incoming picture and processes it to give improved contrast, optimum depth of field and vivid colour tones.



SOUND MENU

The Sound menu will allow you to set your personal preferences for all aspects of sound quality

Open the Sound menu

SOUND

Move to your choice

Increase or decrease levels or set options

Press the TV/AV button to exit the Sound menu

TV/AV



Volume

The Volume adjustment sets the overall output volume.

Bass

Bass adjustment will emphasise the lower, deeper frequencies and can be increased or decreased.

Treble

Treble adjustment will emphasise the sharper, higher frequencies and can be increased or decreased.

Balance

Balance affects the levels of sound between the left and right speakers. Adjustment can be made so that the level from the speakers will suit your listening position.



MPX

MPX will usually be set to Stereo to provide the best reproduction, however if reception deteriorates or if the service is not available then it is advisable to switch to Mono. Mono (M1) and (M2) can also be selected if signals are being transmitted.

Mode

The sound can be improved during Music or Speech mode by selecting the appropriate function.

Ambience

Ambience provides a dynamic enhancer to simulate improved spatial effects.



SETUP MENU

The Setup menu provides access to various advanced features and also to the Tuning menu

Open the Setup menu

SET UP

Move to your choice

Increase or decrease levels, set options or access further menus

Press the TV/AV button to exit the Setup menu

TV/AV



●○ **Teletext**

The Teletext option allows you to choose between FLOF or LIST mode.
See page 24.

●○○○○○○ **Off timer**

Off timer will switch the TV off within a preset time which you can choose from between 0 to 90 minutes in 15 minute intervals.

○● **Flicker reduction**

You will normally find that Flicker reduction is best set to **On** to reduce any slight picture movement. However, it is possible that some occasional broadcasts may benefit by selecting the **Off** position.



○● **Q-Link**

Q-Link allows you to enable or disable data communication with a compatible VCR. See page 21.

Tuning menu

The Tuning menu provides an entry to many other features including Programme edit, ATP, Fine tuning, Manual tuning, Colour system and Volume correction. See page 13.

OSD language

OSD language allows you to select the language used for On Screen Displays. See page 20.



TUNING MENU

The Tuning menu provides access to manual, automatic and fine tuning menus

Open the Setup menu — SET UP

Move to Tuning menu

Access Tuning menu

Move to your choice

Increase or decrease levels, set options or access further menus

Press the TV/AV button to exit — TV/AV







Programme edit

Accessing the Programme edit menu will allow stations to be moved, added, deleted, named or locked and provides access to the TV -system.
See page 14.

Auto setup

The Auto setup menu allows you to automatically retune the TV.
See page 18.

Manual tuning

The Manual tuning menu allows individual programme positions to be tuned manually. See page 19.

Fine tuning

Stations can be finely tuned using the Fine tuning adjustment.

Colour system

The Colour system menu allows you to decide the correct choice of transmission standard.

Volume correc.

Volume correction allows you to adjust the volume level of individual stations.

Decoder (AV2)

This option is used when a decoder is connected via AV2. Set to On if a scrambled signal is to be processed by the decoder. Set to Off after use.

TUNING MENU - PROGRAMME EDIT

The Programme edit menu allows you to edit the programme position settings

Open the Setup menu

SET UP

Move to Tuning menu

Access Tuning menu

Move to Programme edit menu

Access Programme edit menu

Make required changes (see sections below)

Press STR button to store changes

STR

If you have finished in the Programme edit menu, press the TV/AV button to exit

TV/AV





To delete an unwanted programme position

Choose the programme position

Press the Red button on remote control

Press the Red button again to confirm

If you have finished in the Programme edit menu, press the TV/AV button to exit

TV/AV





TUNING MENU - PROGRAMME EDIT

To add a programme position

Choose the programme position where the new program is to be inserted

Press the Green button

Press the Green button again to confirm

This blank programme can then be tuned, named, locked and be allocated your choice of TV-system

Press STR to store

If you have finished in the Programme edit menu, press the TV/AV button to exit



To move a programme to another position

Choose the programme position to be moved

Press the Yellow button on remote control

Choose new position

Press the Yellow button again to confirm

If you have finished in the Programme edit menu, press the TV/AV button to exit





To tune a programme position

Choose the programme position

Move to the channel column

Increase or decrease channel number or use the 'C' key for Direct Channel Access (see page 5)

Press STR to store

STR

If you have finished in the Programme edit menu, press the TV/AV button to exit

TV/AV



To rename a programme position

Choose the programme position

Move to the Name column

Choose the new character

Move to the next character position

Continue until renaming is done

Press STR to store

STR

If you have finished in the Programme edit menu, press the TV/AV button to exit

TV/AV


Change character
Select option
Return -
TV/AV
Exit
'STR' Button
Store
Programme edit
Prog. Chan. Name Lock Sys
1: CH41 XYZ Off SC2
2: - Off SC2
3: CH44 ZXY Off SC2
4: - Off SC2
5: - Off SC2
A B C D E F G H I J K L M N O P Q
R S T U V W X Y Z Ă Ć Č Ě Ł Ř Ś Š
Ş Ţ Ž + - . 0 1 2 3 4 5 6 7 8 9

TUNING MENU - PROGRAMME EDIT

To lock a programme position to prevent access

Choose the programme position

Move to the lock column

Choose between lock on or lock off

Press STR to store

STR

If you have finished in the Programme edit menu, press the TV/AV button to exit

TV/AV

Note :
When a programme position is locked, Direct Channel Access using the 'C' and numeric keys on the remote control is not available.



To change the TV-system for a programme position

Choose the programme position

Move to the Sys column

Choose the required sound system:
SC1 : PAL B/G, H / SECAM B/G
SC2 : PAL I
SC3 : PAL D/K / SECAM D/K
F : SECAM L/L'

STR

Press STR to store

If you have finished in the Programme edit menu, press the TV/AV button to exit

TV/AV



To copy programme information to a compatible VCR connected to AV2

Move to the Prog. column

Press the Blue button on the remote control.
Programme data will now be sent to the VCR. This might take a few seconds, depending on the number of stations stored. If the message "Unable to download, check your VCR" appears on the screen, the television is unable to send the programme information to the VCR. See the VCR handbook for further information.

If you have finished in the Programme edit menu, press the TV/AV button to exit

TV/AV

TUNING MENU - AUTO SETUP (ATP)

The Auto setup menu will allow you to automatically retune the TV to your local stations. It is useful if you move to a different region

Open the Setup menu

SET UP

Move to Tuning menu

Access Tuning menu

Move to Auto setup

Access Auto setup

Press to confirm start

Select your country

Press to start Auto setup (ATP)





The TV will search for, locate and sort into order your local stations. If a compatible VCR is connected via the AV2 socket, programme data will be sent to the VCR via Q-Link (see page 21).

Once this operation is completed the TV will display programme position 1.



TUNING MENU - MANUAL TUNING

Manual tuning of the Programme positions is available either from the On Screen Display menu or from the front panel controls

Manual tuning menu

Open the Setup menu

SET UP

Move to Tuning menu

Access Tuning menu

Move to Manual tuning

Access Manual tuning

Select the programme position to be tuned

Start tuning

When the desired programme is found, press STR to store

STR

Press the TV/AV button to exit.

TV/AV





Manual tuning (Front panel)

Press the F button (Front panel) until “Tuning mode” is reached

F

Press the - or + button to access Tuning mode

-/∨ +/∧



Press the TV/AV button to move between “Change programme”, “Search” or “Change TV system”

TV/AV

Press the - or + button to change programme position, start search, or alter TV system

-/∨ +/∧



When the desired station is found, press STR to store the changes

STR

Repeat above procedure to tune additional programmes or press the F button to exit

F



OSD LANGUAGE

When you first installed the TV the On Screen Display language was set according to your choice of country. If you wish to use a different language then it can be chosen from the OSD language menu

Open the Setup menu

SET UP

Move to the OSD language menu

Access the OSD language menu

Move to your choice

Press the TV/AV button to select and exit

TV/AV





Q-Link allows the television to communicate with your VCR

Open the Setup menu — SET UP

Move to Q-Link

Confirm Q-Link is set to "On"

Press the TV/AV button to exit — TV/AV



The VCR must be connected with a SCART lead (full function type) attached between the AV2 socket of the television and the appropriate socket on your VCR. See the VCR handbook for further information. Q-Link, NEXTVIEWLINK or similar technology allows the television to instruct a **compatible VCR** to record the programme that is currently being displayed on screen, regardless of the programme position set on the VCR, thus simplifying the process of recording programmes.

To record the programme you are currently watching

Press the DIRECT TV REC button on the remote control — DIRECT TV REC

If the VCR is off, it will automatically switch on when you press the DIRECT TV REC button.
A message, sent from the VCR, will appear on screen showing what is being recorded, or if it is not possible to record:

VCR recording preset prog

VCR recording own tuner

VCR is recording the programme signal from its own tuner. If you wish you can switch off the TV and leave the VCR recording in the normal way.

VCR recording TV source

VCR is recording the programme signal from the television. You must not change programme position or switch off the TV: if you do, the VCR will automatically stop recording and switch off.

No recording - TAPE IS PROTECTED

The write protection tab on the back of the cassette has been removed.

Examples of other messages that might be displayed are:

No recording - NO TAPE

No recording - VCR IS PLAYING

VCR recording VCR external

No recording - ALREADY RECORDING

No recording - TAPE MAY BE DAMAGED

No recording - NO SOURCE AVAILABLE

To share tuning information

To ensure correct recordings are made, the television and VCR should share tuning information - see page 17.

- Whenever the Auto setup (ATP) function is used, tuning data will be downloaded to the VCR.

Auto Power functions

With Panasonic Q-Link VCRs these additional features are available:

- If you insert a tape in your VCR and press the Play button, the television will automatically switch on and select the AV2 input so you can view the tape.
- If you switch off the television whilst the VCR is in Stop, Fast Forward or Rewind modes, the VCR will switch off automatically.

To turn off Q-Link communication

If you do not wish to use the Q-Link feature, go to the Setup menu and set the Q-Link option to "Off". See page 12.

Important Note:
Not all VCRs support this type of data communication system. Some may support certain features, but not others. See the VCR handbook for further information.
If Q-Link is inoperative, first confirm that your SCART lead is a full function type. Ask your dealer for further details.

AV SELECT AND SETUP

The AV Select menu will allow you to choose which AV source to view

Press the TV/AV button

TV/AV

Press the appropriate coloured button of remote control (whilst the options remain on screen)

The options will disappear

You may wish to make adjustments to the Setup or Sound menus



Setup menu

Open the Setup menu

SET UP

Move to your choice

Access adjustments or options

Press the TV/AV button to exit

TV/AV



Sound menu

Open the Sound menu

SOUND

Move to your choice

Access adjustments or options

Press the TV/AV button to exit

TV/AV



VCR / DVD OPERATION

The Remote Control is capable of operating some functions of selected Panasonic VCRs and DVD (Digital Versatile Disc) equipment. Some VCR and DVD equipment have different functions, so to ensure compatibility please refer to the equipment's instruction book or consult your dealer for details.

DVD VCR

Standby

Press to switch the VCR or DVD to standby mode. Press again to switch back on.

VCR / DVD switch

Use this switch to select whether controls operate DVD equipment or your VCR.

Play

Press to playback the tape or DVD.

Stop

Press to stop the tape or DVD.

Skip / Fast Forward / Cue

VCR: Press to fast forward the tape. In Play mode, press to view the picture rapidly forward.
DVD: Press once to skip to the next track. In play mode press and hold to view the picture rapidly forward.

Skip / Rewind / Review

VCR: Press to rewind the tape. In Play mode, press to view the picture rapidly in reverse.
DVD: Press once to skip to the previous track. In play mode press and hold to view the picture rapidly in reverse.

Pause / Still

Press in playback mode, the picture will pause. Press again to restart play.

Programme Up / Down

Press to increase or decrease the VCR programme position by one.

REC

Record

Press this button to start recording.

TELETEXT OPERATION

- Teletext features may vary depending on the Broadcasting Companies and is only available if the channel selected is transmitting Teletext.
- Pressing the Picture button whilst in Teletext operation will display the contrast function with a cyan bar, press ◀ ▶to alter the setting as required.
  Pressing the Setup button whilst in Teletext operation will display special function options at the bottom of the screen.
- When in Teletext mode, the volume may still be altered to the desired listening level.

What is LIST mode?

In LIST mode, four differently coloured page numbers are situated at the bottom of the screen. Each of these numbers can be altered and stored in the TV's memory.

What is FLOF (FASTEXT)?

In FASTEXT mode, four differently coloured subjects are situated at the bottom of the display. To access more information about one of these subjects, press the appropriately coloured button. This facility enables fast access to information of the subjects shown.

TV / Teletext mode

Press the **TV/TEXT** button.
The screen will display the Teletext page.
Press again when you wish to return to TV. mode.



Page Selection

Pages can be selected in two ways :
a. Press the Up / Down buttons to increase or decrease the page number by one.
b. By entering the page number, using 0 –9 on the remote control.

Full / Top / Bottom

Press the **SET UP** button to display special functions, followed by the **Green** button.
Press the **Green** button again to expand the BOTTOM half.
Press again to return to normal (FULL) size.

Reveal

Press the **SET UP** button to display special functions, followed by the **Red** button to reveal hidden words e.g. quiz page answers. Press again to hide.



Red / Green / Yellow / Blue buttons

In FASTEXT mode these correspond to the differently coloured subjects.
In LIST mode they correspond to the differently coloured page numbers.

List Store

In LIST mode the four page numbers can be altered for channel positions 1 – 25 only.
To do this, press one of the coloured buttons and enter the new page number.
Press and hold **STR**, the page numbers will change colour.

TELETEXT OPERATION

It is not possible to change the programme position when in News flash, Update or Sub Coded Page Access operation.

HOLD

Hold

To hold the Teletext page when viewing multi-page information.
Press again to return to automatic page update.

F.P.

Favourite Page (F.P.)

Stores a favourite page in memory for instant recall. To store such a page, the TV must be in LIST mode, and the programme position must be from 1 - 25. Press the **Blue** button, select the page number, then press and hold the **STR** button. The page number is now stored.
Press **F.P.** to recall this page.

Update Display

Press the **SET UP** button to display special functions, followed by the **Yellow** button to view the TV picture whilst searching for a Teletext page.
When found, the screen will display the page number at the top left.
Press the **Yellow** button to view the page.
Press **TV** / **TEXT** again to return to normal TV operation.

SET UP

News Flash
When a news flash page has been selected, press **SET UP**, **Yellow**, to view the TV picture. When an update is received, the page number will be displayed on screen.
Press the **Yellow** button to display the News Flash
Press **TV** / **TEXT** to return to normal TV. operation.

Update
Press **SET UP**, **Yellow** to see the update of information on certain pages.
When an update is received, the page number will be displayed at the top left of the screen.
Press the **Yellow** button to view the page.
Press **TV** / **TEXT** to return to normal TV. operation.

Sub Coded Page Access

SET UP

When Teletext information exceeds more than one page, it may take some time for the automatic changing of the sub pages to reach the sub page you require.
It is possible to enter your required sub page and continue watching the normal programme until the correct sub page is found.
Select the required page number using buttons 0 - 9.

Press the **SET UP** button followed by the **Blue** button; T**** will be displayed at the top right of the screen.

Enter desired sub page number before the T**** disappears.
To select page 6 enter 0, 0, 0 and 6.

(If in LIST mode, a 'T' will appear in the current box at the bottom).

Press the **Yellow** button to view a normal TV programme.
(Press **SET UP**, **Yellow** in LIST mode).

When the page is available, press the **Yellow** button to view the page.
To clear the page perform one of the following :

- Press **SET UP**.
- Select a new page number.
- Press **TV**/**TEXT** to return to normal TV operation.

INDEX

Index

Press **INDEX** to return to the main index page.
Depending on the way information is transmitted, this may have to be pressed more than once to return to the main index page.

Front AV3 RCA Audio / Video and Headphone Sockets





Note :
Ancillary equipment and cables shown are not supplied with this TV set.

■ SCART Terminal Information

AV1 21 pin SCART terminal



Suitable inputs for **AV1** include RGB (Red/Green/Blue).

AV2 21 pin SCART terminal



AV2 - Pins 15 and 20 are dependent on AV2 S-VHS / VIDEO switching.

S–Video 4 pin socket



Rear AV1/AV2(S) 21 Pin SCART and RCA Audio Out Terminals



Notes:
Ancillary equipment and cables shown are not supplied with this TV set.
Do not connect a computer with TTL output (5V) to this set.

Symptoms		Checks
Picture	**Sound**	
 Snowy Picture	 Noisy Sound	Aerial location, direction or connection
 Multiple Images	 Normal Sound	Aerial location, direction or connection
 Interference	 Noisy Sound	Electrical appliances Cars / Motorcycles Fluorescent lights Switch on P–NR in Picture menu to reduce picture noise
Normal Picture	 No Sound	Volume level Sound mute switched on
No Picture	 No Sound	TV set to AV mode Not plugged into A.C. outlet Not switched on Picture / Sound controls set at minimum levels Check if in standby mode
 No Colour	 Normal Sound	Colour controls set at minimum levels
 Poor or Distorted Picture	 Weak or No Sound	Retune Channel(s)
Coloured Patches	 Normal Sound	Magnetic Interference from unshielded equipment Receiver moved while switched ON, switch TV off for 30 minutes.
Normal Picture	 Weak or distorted sound	Sound reception may have deteriorated. Switch MPX setting (Sound menu) to Mono until reception improves.

FOR YOUR GUIDANCE

■ Service

Before requesting service, please refer to the troubleshooting guide on previous page to determine the symptoms. To obtain service please contact your local Panasonic dealer quoting the model number and serial number (both are located at the rear of the TV).

■ TV Games / Home Computers

Extended use of TV games or home computers with any television set can cause a permanent 'shadow' on the screen. This type of irreversible picture tube damage, can be limited by observing the following points:

- Reduce the brightness and contrast levels to a minimum viewing level.
- Do not operate the television set for a continuous period of time while using TV games or home computers.
- This type of picture tube damage, is not an operating defect, and as such is not covered by the Panasonic warranty.

■ Last Position Memory

Certain functions have a last position memory, i.e. the setting at the time of switch-off will be the setting used when the receiver is switched on again:-

Programme	Tint
OSD language	(M.NTSC / NTSC only)
AV Position	Contrast
Volume	Sharpness
MPX	Aspect
Bass	Standby
Treble	Artificial Intelligence (AI) – Picture
Balance	Colour
Colour Balance	Brightness
Status	Ambience
P-NR	Teletext mode
Volume correction	Q-Link
Decoder (AV2)	Flicker reduction

■ Sleep Feature

If the set is not switched off when the TV station stops transmitting, it will automatically go to standby mode after 30 minutes. This function will not operate when the TV is in AV mode.

SPECIFICATIONS

		TX-28DK20F
Power Source		220 - 240V 50Hz A.C.
Power Consumption		127W
Standby Consumption		1,4W
Picture Tube Visible Diagonal		66 cm
Audio Output Music Power		2 x 7W RMS (2 x 15W MPO), 8Ω impedance
Dimensions	H W D	514 mm 796 mm 514 mm
Weight		36 kg
Receiving Systems/ Band name		**PAL B/G, H, PAL I, SECAM B/G, SECAM L/L'** VHF E2 - E12 / VHF H1 - H2 (ITALY) VHF A - H (ITALY) / UHF E21 - E69 CATV (S01 - S05) / CATV S1 - S10 (M1 - M10) CATV S11 - S20 (U1 - U10) / CATV S21 - S41 (Hyperband) **PAL D/K, SECAM D/K** VHF R1 - R2 / VHF R3 - R5 VHF R6 - R12 / UHF E21 - E69 **PAL 525/60** Playback of NTSC tape from some PAL video recorders (VCR) **M.NTSC (AV input only)** Playback from NTSC 4,43 MHz Videorecorders (VCR) **NTSC (AV input only)** Playback from NTSC Videorecorders (VCR)
Number of programme positions		99 + VCR
Aerial - Rear		UHF / VHF
Headphones - Front		3,5mm, 8Ω impedance
AV - Rear		**AV1** - 21 pin terminal - Audio / Video in / out, RGB in. **AV2** - 21 pin terminal - Audio / Video in/out, S-Video in, Q-Link 2 x RCA Audio Monitor Out.
AV - Front		**AV3 -** S-Video in, 2 x RCA Audio in, 1 x RCA Video in.

Specifications are subject to change without notice. Weight and dimensions shown are approximate.

NOTES